



3.



MIX02A/02AU/MIX04A/04AU MIX02-1A		
		20 -20
		>0,008%
		-103
		90
	(Mic)	-20 +45
		-20 +25
	+48	.
EQ ()	HI ()	± 15 12
	LOW ()	± 15 80
	/	+21 dBu
		+18 dBu
	(Mic):	2.3 .
	:	20 .
	CD/RCA:	24 .
	/	120
	: RCA	1
		25
	Clip ()	, 0, -10,-20
	100-240	50-60
		11
()	220x160x68	220x210x68
	0,78 (MIX02A/AU)	0,98 (MIX04A/04AU) 165*120*68 0,68 (MIX02-1A)



1.

ON:
OFF:

1:
 2- (MIX02A) 4-
 (MIX04A),
 2/4 / , 48 .
 2 -
 2- CD 3,5 (MIX02-1A)
 , +/- 15 80 & 12
 (L/R)
 / RCA
 1 (MIX02-1A)
 4-
 (100-260 50/60)
 / USB (
 MIX02AU/04AU)



- 1) 0-45
- 2) (12), / 15 .
- 3) (80), / 15 .
- 4)
- 5) L/R
- 6)
- 7)
- 8) RCA
- 9)
- 10)
- 11) +48
- 12) 2TK
- 13)
- 14) -
- CD/DVD-
- 15)
- 16) USB